



Ekioh Configuration

Copyright 2008-2016 Ekioh Ltd.

Release 3.7.3

06 June 2016

Contents

1	Introduction	2
2	Configuration File	3
2.1	Setting Configuration Options	3
2.2	Configuration File Format	3
3	Configuration Options	4
3.1	Generic Configuration Options	4
3.2	UI Engine Configuration Options	10
3.3	WebKit Configuration Options	13
4	Command Line Operation	18
4.1	Command Line Options	19
5	Environment Variables	20
5.1	Environment Variables	20
5.2	ICU Data Location	20
6	SSL Client Certificates	21
6.1	Configuration	21
6.2	Certificate format	21
7	APPENDIX I - Config Names Mapping	22

Introduction

The Ekioh UI Engine and TV Browser are highly configurable and can be tailored to specific needs using a configuration file and command line arguments.

In addition, environment variables can be used for proxy settings, plugin and font directory locations.

This document describes how to configure the Ekioh UI Engine and TV Browser, set the environment variables and accept client certificates.

Further documentation can be found on the Ekioh Releases Page at <https://support.ekioh.com/releases/>.

Configuration File

The Ekioh UI Engine and TV Browser use default configuration settings that can each be overridden by using the Ekioh Configuration File, `ekioh.cfg`. This in turn can be overridden by additional configuration files and command line arguments. This section shows where the configuration file is located, how to override it and the default configuration settings.

2.1 Setting Configuration Options

The default configuration settings can be overridden by using entries in a configuration file, `ekioh.cfg`. The default location for `ekioh.cfg` is the current directory. (This is not necessarily the same directory as the `ekioh` binary).

Additional configuration files can also be used to make additions or amendments to the default and configuration file settings. To specify an additional configuration file, type:

```
ekioh --config-file <config file>
```

All configurations in this additional file are added to those in the default configuration file and if a parameter is set more than once, the one in the additional file is used.

Some configuration options can be set via the command line as described in the next section. Command line settings are added to the defaults and those set in the configuration file in the default location. If the same parameter is given on the command line and in a user specified configuration file, the last to appear on the command line is used.

2.2 Configuration File Format

Configuration file entries are of the format:

```
#comment  
<name>:<value>
```

Configuration Options

Some configuration items can be changed dynamically at runtime via the porting layer. Where dynamic changing is supported, this is noted in the item's description below.

3.1 Generic Configuration Options

Configuration Option	Default	Description
application.background.argb	0xffffffff	Background colour (in ARGB format) for the application to plot on top of. The alpha component is plotted to the screen, rather than blended, allowing video to show through behind the document contents if it is not 0xff. A value of none ensures no background is plotted. This is only of use if some other application controls the framebuffer, otherwise the screen will look corrupt. (<i>Introduced 2.2.1.4</i>).
application.default	[blank]	Specifies the default application • browser: Forces Twin Engine browser builds into TV Browser mode. (<i>Introduced 3.4.1</i>).
application.geometry	720x576	Specifies the size of the window in pixels for desktop builds. For example, "1280x720" for 720p HD. The default window size is SD PAL. (<i>Introduced 2.0.1</i>).
application.homepage	[blank]	Homepage URL to load at startup. (<i>Introduced 2.0.1</i>).
application.language.default	en	Specifies the default language, as defined in rfc4646. (<i>Introduced 2.2.7.2</i>).

Continued on next page

Table 3.1 – continued from previous page

Configuration Option	Default	Description
application.verbose	false	Enables verbose output to the console, useful for tracking down memory or file I/O issues. (<i>Introduced 2.1.8.2</i>).
database.cache-capacity	2MB	The size of the memory cache that should be used for handling database data. This affects both WebStorage and WebSQL. Units are bytes (no suffix), 'KB' or 'MB'. (<i>Introduced 2.2.7. Versions prior to 3.1.1 only accept this value in bytes without a suffix. Renamed in 3.7.2</i>).
database.websql.capacity	5MB	The maximum quota allowed for each database. Units are bytes (no suffix), 'KB' or 'MB'. (<i>Introduced 3.7.2</i>).
database.websql.path	[blank]	The directory path where database files used by the UI Engine should be stored. This includes WebSQL databases. NB: This does not include WebStorage, which has its own configuration option. (<i>Introduced 2.1.8, renamed 3.7.2</i>).
database.websql.trusted-domains	[blank]	A comma-separated list of trusted domains which are allowed to manage the database origins. Note that the 'file:/' domain is referred to as 'localhost' in this list. (<i>Introduced 2.1.8.2, renamed 3.7.2</i>).
database.webstorage.capacity	5MB	The maximum quota allowed for each database. Units are bytes (no suffix), 'KB' or 'MB'. (<i>Introduced 3.7.2</i>).
database.webstorage.legacy	false	Allows selection of the legacy (pre 2.2.5.7) WebStorage database format. Note that this option is ignored if a newer database format is found. When enabled, the 'database.webstorage.path' config option specifies the name of the database file and not a directory. (<i>Introduced 2.2.6.3, renamed 3.7.2</i>).
database.webstorage.originator-events	false	WebStorage StorageEvents are no longer sent to the originator of WebStorage changes as described in the W3C spec. Setting this option to 'true' will reinstate the legacy behaviour of sending StorageEvents to the originator of changes. (<i>Introduced 2.2.9, renamed 3.7.2</i>).
Continued on next page		

Table 3.1 – continued from previous page

Configuration Option	Default	Description
database.webstorage.path	[blank]	The directory in which to store WebStorage databases. If the directory does not exist, it will be created on first use. If blank, the 'window.localStorage' object will not be created. This behaviour alters if the 'database.webstorage.legacy config' option is enabled (see the description of that option for more details). (<i>Introduced 2.2.8.6, renamed 3.7.2</i>).
font.accelerate	true	Hardware-accelerate text (FreeType builds only). Can be disabled on some platforms where the port restricts the performance. Puts an extra burden on the font cache. (<i>Introduced 2.2.7</i>).
font.cache-capacity	2MB	Size of the font cache (FreeType builds only). Units are bytes (no suffix), KB or MB. Prior to version 3.5 this defaulted to 1MB. (<i>Introduced 2.0.1, renamed 3.7.2</i>).
font.default	[blank]	The name of the default (fallback) font. This is used if the font name is not found or not specified. If this option is not specified, the first font loaded will be the default. This is the first font included in the build or, if none, the first found in the search path. (<i>Introduced 2.1.1</i>).
font.fallback	[blank]	A comma-separated list of fallback fonts (as per the CSS property 'font-family'). The fallback font is used when the specified or default font is missing a required glyph. (<i>Introduced 2.2.5.7</i>).
font.hinting	false	Configure font hinting. (<i>FreeType introduced in 2.2.2.10, iType introduced in 3.5.3, renamed in 3.7.2</i>).
font.path	[blank]	Directory path to search for dynamically loadable fonts. Multiple paths can be specified using the platform's path separator character (':' on Unix systems). (<i>Introduced 2.1.1</i>).
filters.accelerate.gpu	true	Enables the use of hardware accelerated filter effects (if supported). When false, all filter effects are performed in software. (<i>Introduced 2.2.6.3, renamed in 3.7.2</i>).
Continued on next page		

Table 3.1 – continued from previous page

Configuration Option	Default	Description
geolocation.preset	[blank]	For platforms with no geolocation support, this option specifies the latitude, longitude (degrees) and accuracy (metres) as space-separated numbers. e.g. for a 5km radius from central Cambridge, '52.205282 0.117811 5000'. (<i>Introduced 2.1.8.4</i>).
network.cookie.database	[blank]	The filename of any cookie database. If present, this is loaded on EKLibrary startup, and saved on shutdown. The file may be read-only, in which case it is not overwritten on shutdown. No error is generated if the file does not exist, or cannot be read. (<i>Introduced 2.0.1</i>).
network.digest.database	[blank]	The filename of any digest database for use by digest authentication. If present, this is loaded on EKLibrary startup, and saved on shutdown. The file is expected to be populated via JavaScript APIs rather than by hand. The password is stored as an MD5 digest rather than plaintext. (<i>Introduced 2.0.1</i>).
network.http.accept-language	[blank]	The given string is used as the 'Accept-Language' option in HTTP and HTTPS requests. (<i>Introduced 2.2.4.3 , renamed 3.7.2</i>).
network.http.gzip	true	Enable notification of gzip support in HTTP requests. With this false, gzip responses are never requested but are still accepted and uncompressed if received. (<i>Introduced 2.0.3</i>).
network.http.keep-alive	true	Support HTTP keep-alive. When disabled, connections are closed when their request completes. (<i>Introduced 2.1.8.5, renamed 3.7.2</i>).
network.http.keep-alive.timeout	0	HTTP keep-alive timeout, in milliseconds. Connections which have been idle (no requests) for this period of time will be closed. A timeout value of 0 will cause connections to be kept alive indefinitely. (<i>Introduced 3.1.2, renamed 3.7.2</i>).
network.http.max-connections	30	The total number of concurrent asynchronous connections (all servers). (<i>Introduced 2.2.4.1</i>).
network.http.max-connections-per-server	15	The total number of concurrent asynchronous connections per server. (<i>Introduced 2.2.4.1</i>).
Continued on next page		

Table 3.1 – continued from previous page

Configuration Option	Default	Description
network.http.redirection-limit	20	The total number of HTTP redirects before aborting the connection. (<i>Introduced 2.1.3</i>).
network.ipv6	false	IPV4 sockets are created by default, if enabled IPV6 sockets are created. (<i>Introduced 2.2.2.5</i>).
network.proxy.http	[blank]	A URL to a proxy used for http traffic e.g. http://192.168.0.1:3128. If this option is blank the platform's proxy settings are used, e.g. http_proxy environment variable when running on Linux. (<i>Introduced 2.2.5.8, renamed 3.7.2</i>).
network.proxy.https	[blank]	A URL to a proxy used for https traffic e.g. https://192.168.0.1:3128. If this option is blank the platform's proxy settings are used, e.g. https_proxy environment variable when running on Linux. (<i>Introduced 2.2.5.8, renamed 3.7.2</i>).
network.proxy.no-proxy	[blank]	A comma-separated list of sites, domains and addresses to not proxy. To match all hosts on a given domain, prefix the domain with a dot (e.g. '.ekioh.com' to match both www.ekioh.com and support.ekioh.com). To match a range of IP addresses use CIDR format (e.g. 192.168.0.0/16 or 2001:db8::/48). (<i>Introduced 3.0.1, renamed 3.7.2</i>).
plugin.mime-types.autoload	[blank]	A comma separated list of mime-types specifying the plugins which are to be automatically instantiated on every page. Whitespace is not allowed within the list of mime-types. (<i>Introduced 2.2.5.9</i>).
plugin.mime-types.force-solid	[blank]	A list of plugin MIME types and colours in the form <MIME type>,<hex colour>;<MIME type>,<hex colour> for which the browser should draw a solid rectangle instead of passing paint events to the plugin. For example video/broadcast,0x00000000. (<i>Introduced 3.4.3</i>).
plugin.mime-types.no-unload	[blank]	A list of plugin MIME types that should never be unloaded once they've been loaded. (<i>Introduced 3.6.1</i>)
Continued on next page		

Table 3.1 – continued from previous page

Configuration Option	Default	Description
plugin.path	[blank]	Directory path to search for dynamically loaded plugin libraries. Multiple paths can be specified using the platform's path separator character (':' on Unix systems). If plugin.path is blank, the EK_PLUGIN_DIR environment variable is used instead. If EK_PLUGIN_DIR is not specified then no plugins are loaded. <i>(Introduced 2.2.2.4).</i>
ssl.cafile	[blank]	A file of CA certificates in PEM format. See OpenSSL for more information. <i>(Introduced 2.0.1).</i>
ssl.capath	[blank]	A directory containing CA certificates in PEM or DER (.der extension) format (one certificate per file). The OpenSSL c_rehash utility must be used to generate appropriately named links to the certificate files. See OpenSSL for more information. <i>(Introduced 2.0.1).</i>
ssl.client-certs.path	[blank]	A directory containing customised .pem files which each contain a client certificate and associated private key and password. <i>(Introduced 2.2.9.1, renamed 3.7.2).</i>
ssl.compression	false	Enabling compression will speed up connections but also make them less secure. <i>(Introduced 2.3.1, renamed 3.7.2).</i>
ssl.crlfile	[blank]	The location of any CRL file to use for certificates specified by both oipf.widget.cafile and ssl.cafile or ssl.capath. <i>(Introduced 2.1.0).</i>
ssl.default-certs	true	Enable a set of built-in certificates from common root authorities. <i>(Introduced 2.2.2.12, renamed 3.7.2).</i>
ssl.js-install-certs	false	When true, allows scripts to install server certificates locally (for that session). This enables a fully trusted security path to external servers without requiring the certificates to be installed on the STB in its flash image. Note that incorrect setup can make this a security risk; all documents must be loaded over HTTPS with verified certificates. <i>(Introduced 2.2.2.12, renamed 3.7.2).</i>
ssl.protocol.rc4	false	When enabled, will allow the use of less secure RC4 ciphers. https://tools.ietf.org/html/rfc7465 <i>(Introduced 3.3.3, renamed 3.7.2).</i>
Continued on next page		

Table 3.1 – continued from previous page

Configuration Option	Default	Description
ssl.protocol.ssl3	false	When enabled, will allow SSLv3 connections to be used. (<i>Introduced 3.1.1, renamed 3.7.2</i>).
ssl.protocol.tls	true	When enabled, the application will request SSLv3 connections instead of TLS. (<i>Introduced 2.2.8.7, renamed 3.7.2</i>).
ssl.verify	true	Verify the server certificate against the internal certificates. It is strongly recommended not to set this to false in deployment situations, but it can be useful during development. A value of false is equivalent to automatically clicking ‘OK’ on a web browser’s dialogue querying an untrusted certificate. (<i>Introduced 2.0.1</i>).
ssl.verify.hostname	true	Validate the hostname of the remote server against the Subject Alternative Name or Common Name fields of the server certificate. (<i>Introduced 2.2.4.7, renamed 3.7.2</i>).
platform.font-manager.win32	false	Enables the Windows font manager in builds that include it. When false, the default built in font manager is used. (<i>Introduced 2.2.7, renamed 3.7.2</i>).

3.2 UI Engine Configuration Options

UI Engine Configuration Option	Default	Description
ekioh.debugger	false	Enable Selenium WebDriver support in the UI Engine. (<i>Introduced 2.2.6, renamed 3.7.2</i>).
ekioh.debugger.highlight-colour	0x8033b5e5	Colour (in ARGB format) of the SVG DOM Inspector highlight. (<i>Introduced 2.2.8.7, renamed 3.7.2</i>).
ekioh.debugger.highlight-duration	-1	Time in milliseconds for which the SVG DOM Inspector highlight should be shown. Set to -1 to display constantly, or 0 to hide it completely. (<i>Introduced 2.2.8.7, renamed 3.7.2</i>).
ekioh.debugger.log-capacity	100	Maximum number of entries which can be kept in the Selenium WebDriver log buffer. If this size is exceeded then new log entries will overwrite the old ones. (<i>Introduced 3.1.2, renamed 3.7.2</i>).

Continued on next page

Table 3.2 – continued from previous page

UI Engine Configuration Option	Default	Description
ekioh.debugger.poll-interval	100	Time interval in milliseconds between element checks when waiting for a search timeout. (<i>Introduced 2.2.7, renamed 3.7.2</i>).
ekioh.debugger.port	4444	Port on which the Selenium WebDriver should listen for incoming connections. (<i>Introduced 2.2.6, renamed 3.7.2</i>).
ekioh.error-page	[blank]	URL of error page to display on UI Engine fetch failure. Details of the error, if available, are supplied as semicolon separated key-value pairs in the query field of the URL: • <code>httpStatusCode=<number></code> • <code>httpStatusText=<string></code> E.g. <code>file:///etc/error.svg? httpStatusCode=404; httpStatusText=NotFound</code> (<i>Introduced 2.1.8, renamed 3.7.2</i>).
ekioh.font.size	16	Default font size for regular text, in pixels. (<i>Introduced 2.2.4.7, renamed 3.7.2</i>).
ekioh.framerate	50	Number of frames per second to attempt to frame limit to. (<i>Introduced 2.2.4.7, renamed 3.7.2</i>).
ekioh.gc.periodic	5000	Default timeout, in milliseconds, between periodic checks for whether a garbage collect should be attempted. This does not mean a garbage collection occurs this frequently. (<i>Introduced 2.1.8.4, renamed 3.7.2</i>).
ekioh.image.accelerate.bmp	false	Accelerate all BMP images, regardless of buffered-rendering property. (<i>Introduced 2.1.7, renamed 3.7.2</i>).
ekioh.image.accelerate.gif	false	Accelerate all GIF images, regardless of buffered-rendering property. (<i>Introduced 2.1.7, renamed 3.7.2</i>).
ekioh.image.accelerate.jpeg	false	Accelerate all JPEG images, regardless of buffered-rendering property. (<i>Introduced 2.1.7, renamed 3.7.2</i>).
ekioh.image.accelerate.png	false	Accelerate all PNG images, regardless of buffered-rendering property. (<i>Introduced 2.1.7, renamed 3.7.2</i>).
Continued on next page		

Table 3.2 – continued from previous page

UI Engine Configuration Option	Default	Description
ekioh.image.load-timeout	0	Timeout value used when fetching images, given in milliseconds. If an image hasn't been loaded in this time it is considered to have failed and aborted. A timeout value of 0 means no timeout is set. (<i>Introduced 2.2.5.9, renamed 3.7.2</i>).
ekioh.js.heap.capacity	4MB	Size of the UI Engine's JavaScript heap. Units are bytes (no suffix), KB or MB. The value is automatically doubled on 64bit systems. (<i>Introduced 2.0.1 - versions prior to 3.1.1 will only accept this value in bytes and MB. Renamed in 3.7.2</i>)
ekioh.js.heap.full-warning	64KB	Amount of free memory available in the JavaScript heap before a low memory event is sent to the document (after a garbage collect). Units are bytes (no suffix), KB or MB. (<i>Introduced 2.1.7 - versions prior to 3.1.1 could match KB and MB case insensitively. Renamed in 3.7.2</i>).
ekioh.layer.debug	false	Enables debug borders and paint counters for SVG layers. (<i>Introduced 2.2.7, renamed 3.7.2</i>)
ekioh.network.svg-connection.security	true	Set the security for the legacy SVG Connection object. When enabled, a connection can only be made to the server at the document's origin. When disabled, a connection can be made to any server, regardless of the document's origin. (<i>Introduced 2.1.8.4, renamed 3.7.2</i>).
ekioh.network.user-agent		Allows the UI Engine user agent string to be overridden. This option may be changed at runtime by the porting layer. The following substitutions are supported: • %b Ekioh build number • %d Build date • %e Ekioh version number • %% A literal % character (<i>Introduced 2.2.4.10, renamed 3.7.2</i>).
ekioh.profiling	false	Output profiling information for various operations (see Ekioh UI Engine Embedded Tools Document for more details). (<i>Introduced 2.1.8, renamed 3.7.2</i>).
Continued on next page		

Table 3.2 – continued from previous page

UI Engine Configuration Option	Default	Description
ekioh.threads.cores	0	Selects number of cores available for task threads. “0” means run everything on the main thread (no threads), and higher numbers run tasks in parallel to the main thread. A value of “1” can be used on single-core CPUs to decode images in a separate thread to redraw, possibly improving animations. (Introduced 3.5.0, renamed in 3.7.2).
ekioh.websocket	true	Enable WebSocket support for the UI Engine. (Introduced 3.7.2).
oipf.widget.storage.nv-basepath	[blank]	Basepath for the persistent NV storage that will be prefixed to all filepaths sent to the NV file methods. There should be no trailing slash (‘/’) on the basepath. (Introduced 2.0.2, renamed in 3.7.2).
oipf.widget.storage.ram-basepath	[blank]	Basepath for the RAM/local FS storage that will be prefixed to all filepaths sent to the RAM/local FS file methods. There should be no trailing slash (‘/’) on the basepath. (Introduced 2.0.2, renamed in 3.7.2).
oipf.widget.ca-digital-signature	false	States whether CAs and Sub-CA certificates must have the DigitalSignature key usage bit to be verified as valid. (Introduced 2.0.2, renamed in 3.7.2).
oipf.widget.cafile	[blank]	The location of the top level CA Authority certificate used to verify the certificate chain passed to the OIPF Application Manager when a Widget install occurs. (Introduced 2.0.2).
oipf.widget.max-size	15MB	Maximum installable Widget size. This is tested as the size of the .wgt file to install, and not the decompressed Widget. Units are bytes (no suffix), ‘KB’ or ‘MB’. (Introduced 2.0.2 - versions prior to 3.1.1 only accept this value in MB without a suffix. Renamed in 3.7.2).

3.3 WebKit Configuration Options

The following configuration options are available for browser enabled builds:

WebKit Configuration Option	Default	Description
font.downloadable	true	Downloadable font support (currently browser only). (<i>Introduced 2.2.1.10</i>).
webkit.application-cache.path	[blank]	Location to store resources for HTML Offline Web applications. The feature is disabled if this is left blank. (<i>Introduced 2.2.6, renamed 3.7.2</i>).
webkit.application-cache.capacity	[blank]	Quota for HTML Offline Web applications in bytes. There is no quota if this is left blank. (<i>Introduced 2.2.6, renamed 3.7.2</i>).
webkit.caret-width	1	Width in pixels of the browser text caret. (<i>Introduced 2.2.8.2, renamed in 3.7.2</i>).
webkit.compositing	true	Enables or disables accelerated compositing in the browser. (<i>Introduced 2.2.7.7, renamed 3.7.2</i>).
webkit.compositing.debug	false	Enable display of debug borders and repaint counters for composited content in browser builds that support compositing. (<i>Introduced 2.2.5.9, renamed 3.7.2</i>).
webkit.compositing.force	false	Force compositing in builds that support it, even if the content doesn't require it. (<i>Introduced 2.2.6, renamed 3.7.2</i>).
webkit.compositing.gpu	true	Force the use of the 2D compositing in browser builds that support 3D compositing. (<i>Introduced 2.2.6, renamed 3.7.2</i>).
webkit.error-page	[blank]	URL of local error page to display on browser load failure. Details of the error, if available, are supplied as semicolon separated key-value pairs in the query field of the URL: • httpStatusCode=<number> • httpStatusText=<string> E.g. file:///etc/error.html? httpStatusCode=404; httpStatusText=NotFound (<i>Introduced 2.2.8.5, renamed 3.7.2</i>).
webkit.focus-outline.force	false	Display focus outline in browser, even on sites that disable it with CSS outline:none. (<i>Introduced 2.2.2.4, renamed 3.7.2</i>).
webkit.font.size	16	Default font size used by the browser to display regular text. (<i>Introduced 2.2.1.3, renamed 3.7.2</i>).
webkit.font.size.logical-minimum	5	Minimum logical font size used by the browser to display text. Applies when the browser view is zoomed out. (<i>Introduced 2.2.1.3, renamed 3.7.2</i>).

Continued on next page

Table 3.3 – continued from previous page

WebKit Configuration Option	Default	Description
webkit.font.size.minimum	5	Minimum font size used by the browser to display text. <i>(Introduced 2.2.1.3, renamed 3.7.2).</i>
webkit.font.size.monospace	16	Default font sized used by the browser to display monospaced text. <i>(Introduced 2.2.1.3, renamed 3.7.2).</i>
webkit.history.control.keys	true	Enables browser navigation by mapping DOM_VK_BACK and DOM_VK_FORWARD. <i>(Introduced 2.3.4, renamed 3.7.2).</i>
webkit.image.accelerate.all	false	Force all bitmap images to be accelerated, with system memory fallback if out of graphics memory. <i>(Introduced 2.2.4.7, renamed 3.7.2).</i>
webkit.image.auto-load	true	Allows auto-loading of images to be disabled. This option may be changed at runtime by the porting layer. Any images already loaded and cached are still displayed, but new images are not fetched or displayed. Reenabling the option refetches any uncached images and redisplay all images. <i>(Introduced 3.2.1, renamed 3.7.2).</i>
webkit.image.broken-icon	true	Display the broken image icon when an image cannot be loaded. <i>(Introduced 2.2.4.4, renamed in 3.7.2).</i>
webkit.image.max-pixels	[blank]	Limit the maximum number of pixels per decoded GIF, JPEG & PNG image in the browser. Units are pixels, with an optional K or M suffix. There is no limit if this option is not specified. <i>(Introduced 3.1.1, renamed 3.7.2).</i>
webkit.image.progressive	true	Enables or disables progressive rendering of images. <i>(Introduced 2.2.7.7, renamed 3.7.2).</i>
webkit.image.quality	medium	Bitmap image scaling quality in the browser. • low: nearest-neighbour scaling • medium: bilinear interpolation • high: currently equivalent to medium <i>(Introduced 2.2.5.8, renamed 3.7.2).</i>
webkit.media-controls.keys	false	Enable HTML5 video support for media control keys. <i>(Introduced 2.2.7.4, renamed 3.7.2).</i>
webkit.mse	false	Enable HTML5 media source extensions. This may alter the page behaviour if not fully implemented in the porting layer. <i>(Introduced 2.3.1, renamed 3.7.2).</i>
Continued on next page		

Table 3.3 – continued from previous page

WebKit Configuration Option	Default	Description
webkit.mse.buffer.capacity	16MB	Maximum size for a media source buffer. Units are bytes (no suffix), KB or MB. Supported in WebKit600 or later. (<i>Introduced 3.4.2, renamed 3.7.2</i>).
webkit.mse.buffer.eviction-window	30	Size in seconds of the WebKit media source window for evicting played media samples. (<i>Introduced 3.6.2, renamed 3.7.2</i>).
webkit.mse.buffer.video-percentage	95	Percentage size of a media source buffer which is assumed to be for video. Value must be in range 0-100. Supported in WebKit600 or later. (<i>Introduced 3.5.3, renamed 3.7.2</i>).
webkit.network.cache-capacity	4MB	Size of the browser's cache. Units are bytes (no suffix), 'KB' or 'MB'. (<i>Introduced 2.0.1, versions prior to 3.1.1 only accept this value in MB or bytes, renamed in 3.7.2</i>).
webkit.network.user-agent		Allows the HTML browser user agent string to be overridden. This option may be changed at run-time by the porting layer. The following substitutions are supported: • %e Ekioh version number • %p Platform name • %w WebKit version number • %% A literal % character (<i>Introduced 2.2.2.9, renamed 3.7.2</i>).
webkit.plugins	true	Disable loading of plugins in the browser. (<i>Introduced 2.2.2.9, renamed 3.7.2</i>).
webkit.scripting-bridge	false	Determines whether the SVG and browser JavaScript runtimes can communicate. (<i>Introduced 3.3.4, renamed 3.7.2</i>).
webkit.spatial-navigation	true	Determines whether WebKit's spatial navigation mode is activated. If enabled, it is possible to select focusable page items using the up/down/left/right keys. (<i>Introduced 3.1.2, renamed 3.7.2</i>)
webkit.stylesheet.user	[blank]	URL of user style sheet for the browser. (<i>Introduced 2.2.4.10, renamed 3.7.2</i>).
Continued on next page		

Table 3.3 – continued from previous page

WebKit Configuration Option	Default	Description
webkit.text-selection	true	Enables or disables text selection in the browser. This option may be changed at runtime by the porting layer. While enabled, touch scrolling will be disabled. (<i>Introduced 2.2.4.2, renamed 3.7.2</i>).
webkit.video.aspect-ratio.preserve	true	Enables or disables the preserving of the aspect ratio for a video source when embedded into a <video> element. This is only supported in versions of WebKit up to and including WebKit537; use the CSS object-fit property to control the video aspect ratio from WebKit600. (<i>Introduced 2.2.3.8, renamed 3.7.2</i>).
webkit.viewport.configurable	false	Enables the viewport meta tag feature. This allows the content to change the scale and dimension of the user-agent's viewport. (<i>Introduced 2.2.2.3, renamed 3.7.2</i>).
webkit.viewport.device-width	0	Sets the device width used for calculating the viewport size and scale when the viewport is configurable. If this option is set to 0, the current size of main frame is used for the calculation. (<i>Introduced 2.2.2.3, renamed 3.7.2</i>).
webkit.webgl	false	Enables WebGL in the browser. (<i>Introduced 2.2.7, renamed 3.7.2</i>).
webkit.webgl.multisampling	false	Enables multisampling (anti-aliasing) for WebGL. This is currently always disabled for OpenGL ES 2.0 platforms. (<i>Introduced 2.2.7, renamed 3.7.2</i>).
webkit.websocket	true	Enable WebSocket support for the browser. (<i>Introduced 3.7.2</i>).

Command Line Operation

Some configuration items have been mapped onto command line options which can be run with arguments as described below.

Command line options must begin with either a single or double dash.

If more than one command line option is specified for the same parameter, the last one to appear on the command line is used with the exception that `-config-file` and `-optional-config-file` may be specified multiple times.

If more than one configuration file is specified on the command line, the configuration options from all files are used with conflicts handled as described in the Setting Configuration Options section.

Several Ekioh windows can be opened by listing them as arguments. An argument that does not begin with either `-` or `- -` will signify the end of the command line options and all following arguments will be considered to be URLs or documents to be loaded.

4.1 Command Line Options

Syntax	Action
-config-file <config file>	Specify additional config file and quit if not found.
-optional-config-file <config file>	Specify additional config file and continue if not found.
-geometry <width>x<height>	Set application geometry (application.geometry).
-url <URL>	Set URL to load at start up (application.homepage).
-verbose	Run in verbose mode (application.verbose).
-version	Display Ekioh version.
WebKit enabled builds	
-webkit	Forces Twin Engine builds into TV Browser mode (application.default:browser). Also -browser.
-webkit-cache-capacity <size>	Set webkit cache capacity (webkit.network.cache-capacity). Also -browser-cache-capacity.

Environment Variables

The following environment variables are supported.

5.1 Environment Variables

The environment variables below can be used to control the behaviour. They each have equivalent configuration options which can be set in the configuration file. If the equivalent is specified in the configuration file, it will overwrite the environment variable.

Environment Variable	Configuration Equivalent	Operating System
http_proxy	network.proxy.http	Linux, Mac OS X
https_proxy	network.proxy.https	Linux, Mac OS X
no_proxy	network.proxy.no-proxy	Linux, Mac OS X
EK_PLUGIN_DIR	plugin.path	Linux, Windows, Mac OS X

5.2 ICU Data Location

Browser enabled builds use a built in ICU library for Unicode text handling which supports US-ASCII, ISO-8859-1 and Unicode. To use a different ICU Data file, the environment variable ICU_DATA must be set to show its location. The command for this in a Bourne style shell would be:

```
export ICU_DATA=<ICU Data Directory>
```

SSL Client Certificates

It is possible to configure Ekioh so that it accepts client certificates. When a secure server requests one during an SSL handshake, those specified will be analysed and if any match, will be sent to the server.

6.1 Configuration

The `ssl.client-certs.path` configuration option specifies the directory in which the client certificates can be found. These files should have the `.pem` extension and each contain only one certificate. Any certificates that have expired will be ignored.

6.2 Certificate format

The format of the certificate files is customised slightly so that all necessary information is stored conveniently in one place. The following three pieces of information are expected to exist within each file:

Certificate

This will be a Base64 encoded set of data enclosed by the `-----BEGIN CERTIFICATE-----` and `-----END CERTIFICATE-----` statements. It is also a requirement that the certificate is signed with an organisation name as this is used for matching against server certificates. This organisation name is specified in the `subject` and `issuer` lines of the certificate and must therefore also exist within the file.

Private Key

This will be a Base64 encoded set of data enclosed by the `-----BEGIN RSA PRIVATE KEY-----` and `-----END RSA PRIVATE KEY-----` statements. The key encryption will also be detailed within these statements.

Password

This is necessary to decode the certificate and private key and must be specified in the format: `"password:<password>"`.

These three components can be specified in any order within a `.pem` file.

APPENDIX I - Config Names Mapping

The naming of the config items has been revised in 3.7.2. All earlier items still work and this is a mapping of previous names onto current names.

Old config option name	New config option name
application.threads.cores	ekioh.threads.cores
application.websocket	Introduced 2.2.2.7, deprecated in 3.7.2 and superseded with two config options: ekioh.websocket and webkit.websocket
browser.brokenimage.enabled	webkit.image.broken-icon
browser.cache.capacity	webkit.network.cache-capacity
browser.caret.width	webkit.caret-width
browser.compositing.3d.disable	webkit.compositing.gpu
browser.compositing.debug	webkit.compositing.debug
browser.compositing.enabled	webkit.compositing
browser.compositing.force	webkit.compositing.force
browser.errorpage	webkit.error-page
browser.font.size.default	webkit.font.size
browser.font.size.fixed.default	webkit.font.size.monospace
browser.font.size.logical.minimum	webkit.font.size.logical-minimum
browser.font.size.minimum	webkit.font.size.minimum
Continued on next page	

Table 7.1 – continued from previous page

Old config option name	New config option name
browser.image.accelerate.all	webkit.image.accelerate.all
browser.image.auto-load	webkit.image.auto-load
browser.image.max-pixels	webkit.image.max-pixels
browser.image.rendering.progressive	webkit.image.progressive
browser.image.rendering.quality	webkit.image.quality
browser.media.controls.css	webkit.media-controls.css
browser.media.controls.keys	webkit.media-controls.keys
browser.mediasource.buffer.eviction.window	webkit.mse.buffer.eviction-window
browser.mediasource.buffer.maxsize	webkit.mse.buffer.capacity
browser.mediasource.buffer.video.percentage	webkit.mse.buffer.video-percentage
browser.mediasource.enabled	webkit.mse
browser.navigation.enabled	webkit.history.control.keys
browser.network.useragent	webkit.network.user-agent
browser.offlineappcache.path	webkit.application-cache.path
browser.offlineappcache.quota	webkit.application-cache.capacity
browser.outline.force	webkit.focus-outline.force
browser.plugins.disable	webkit.plugins
browser.scripting.bridge.enabled	webkit.scripting-bridge
browser.spatialnavigation	webkit.spatial-navigation
browser.stylesheet.user	webkit.stylesheet.user
browser.text.selection.enabled	webkit.text-selection
browser.video.aspectratio.preserve	webkit.video.aspect-ratio.preserve
browser.viewport.configurable	webkit.viewport.configurable
browser.viewport.device.width	webkit.viewport.device-width
browser.webgl	webkit.webgl
browser.webgl.multisampling	webkit.webgl.multisampling
font.cache.capacity	font.cache.capacity
Continued on next page	

Table 7.1 – continued from previous page

Old config option name	New config option name
graphics.filters.accelerate	filters.accelerate.gpu
network.http.accept.language	network.http.accept-language
network.http.keepalive	network.http.keep-alive
network.http.keepalive.timeout	network.http.keep-alive.timeout
network.http.noproxy	network.proxy.no-proxy
network.http.proxy	network.proxy.http
network.https.proxy	network.proxy.https
oipf.nvstorage.basepath	oipf.widget.storage.nv-basepath
oipf.ramstorage.basepath	oipf.widget.storage.ram-basepath
oipf.widget.cadigitalsig	oipf.widget.ca-digital-signature
oipf.widget.maxsize	oipf.widget.max-size
ssl.certs.default.enable	ssl.default-certs
ssl.certs.js.install	ssl.js-install-certs
ssl.client.certs.path	ssl.client-certs.path
ssl.compression.enable	ssl.compression
ssl.disable.tls	ssl.protocol.tls
ssl.rc4.enable	ssl.protocol.rc4
ssl.ssl3.enable	ssl.protocol.ssl3
ssl.validate.hostname	ssl.verify.hostname
svg.database.cache.size	database.cache-capacity
svg.database.maxquota	Introduced 2.1.8.2, deprecated in 3.7.2 and superseded with two config options: database.websql.capacity and database.webstorage.capacity
svg.database.path	database.websql.path
svg.database.trusteddomains	database.websql.trusted-domains
svg.errorpage	ekioh.error-page
Continued on next page	

Table 7.1 – continued from previous page

Old config option name	New config option name
svg.font.size.default	ekioh.font.size
svg.framerate	ekioh.framerate
svg.gc.periodic	ekioh.gc.periodic
svg.image.accelerate.bmp	ekioh.image.accelerate.bmp
svg.image.accelerate.gif	ekioh.image.accelerate.gif
svg.image.accelerate.jpeg	ekioh.image.accelerate.jpeg
svg.image.accelerate.png	ekioh.image.accelerate.png
svg.image.load.timeout	ekioh.image.load-timeout
svg.jsheap.full.warning	ekioh.js.heap.full-warning
svg.jsheap.size	ekioh.js.heap.capacity
svg.layers.debug	ekioh.layer.debug
svg.network.connection.security	ekioh.network.svg-connection.security
svg.network.useragent	ekioh.network.user-agent
svg.profilng	ekioh.profilng
svg.webdriver.enabled	ekioh.debugger
svg.webdriver.highlight.colour	ekioh.debugger.highlight-colour
svg.webdriver.highlight.time	ekioh.debugger.highlight-duration
svg.webdriver.log.size	ekioh.debugger.log-capacity
svg.webdriver.poll.interval	ekioh.debugger.poll-interval
svg.webdriver.port	ekioh.debugger.port
svg.webstorage.database	database.webstorage.path
svg.webstorage.legacy.enable	database.webstorage.legacy
svg.webstorage.originator.events	database.webstorage.originator-events
win32.font.enable	platform.font-manager.win32